



## **INSTALLATION INSTRUCTIONS**

### **Electronic Wall Unit FOR ELECTRIC KILNS**

Olympic's electronic wall unit features programming by cone number or allows you to create your own programs. Each program has eight segments with ramp/hold profiles and controlled cooling rate. The controller also features numerous means for diagnosing problems and convenient program review before or during a firing.

1. Attach wall mount control vertically to wall.
2. Plug or direct wire Wall Unit to the power source
3. Plug or direct wire the kiln into the wall unit
4. Drill a 1/4" hole through the kiln wall and insert thermocouple from wall unit into the kiln. Insert thermocouple approximately 1 1/2" inside the kiln.
5. Place a junior cone that is one size hotter than you intend to fire into the kiln sitter and activate the kiln sitter.
6. Turn all switches on the kiln to the high setting.
7. Read electronic control instructions thoroughly and following programming instructions that best suit your firing requirements.

